



100mm Window Fixing Kit
for
SDF100 and SVC100 Ranges

SDF901WFK

Fitting Instructions

It is strongly advised that mounting the kit is a two person operation.

Hole size required: 127mm-140mm diameter.

Glazing thickness 16mm-30mm

1. Remove front grille (MM5) from window kit
2. Gently press the foam strip into the grooves of window fixing moulding to form a watertight, weather seal.
3. Remove the front cover of the fan and drill a hole (the size of the wire you are using) in the following positions:-
 - SDF100 - Bottom, 4cm from RHS
 - SVC100 - LHS, 2cm from the top
4. Clean the window glass before assembly
5. From the outside, push the window fixing moulding (MM4) through the hole in the glass **taking care not to over strain the glass**. Please ensure the part is fitted in the correct orientation
6. From the inside, push the fan through the hole in the glass **taking care not to over strain the glass**.
7. Secure the two parts together with the 4 fixing screws supplied with this kit
8. Secure external grille (MM5) with 2 screws supplied with this kit
9. Make electrical connections following the fan's instructions
10. Fit the internal grille, locating it over the top lip before engaging bottom screw

Domus Ventilation Block C
Caerphilly Business Park
Caerphilly
CF83 3ED
UK

UK Tel: 03443 715523
UK Fax: 03443 715524

International tel: +44 (0)1302 348878
International fax: +44 (0)1302 348879

Email: vent.info@domusventilation.co.uk
Web: www.domusventilation.co.uk