

Here is the photo of the CFCH controller with the membrane correctly fitted and incorrectly fitted. The controller will not function correctly until the membrane is installed properly.

The process is as follows:

PLEASE NOTE THAT THE PCB IS STATIC SENSITIVE!

Isolate supply to controller.

Remove the 2 cover fixing screws at the bottom of the controller.

Remove the front cover.

Remove the two screws that hold the PCB in place, and remove the PCB (Note the PCB orientation).

Remove the two grey rubber membranes, transpose them so that they match figure No 1.

Assemble in reverse order.

