

MAGDUOCP MAGDUOCP65 IP Version
Call Point for MAGDUO

- Resettable manual call point
- Built-in End of Line function
- Device base included



MAGDUOIOR
Module for MAGDUO

- Configure as an input for reporting from other systems or devices
- Configure as an output to control external systems
- Built-in End of Line function




MAGDUOBBB
Battery Expansion Box for MAGDUO

- Includes; conduit bushes, coupling and battery leads



MAGDUOSHDB
Deep Base for MAGDUO Devices

- For use with; FlexiPoint devices, internal ceiling sounders & strobes



MAGDUOZC4
MAGDUO4 Zone Expansion Card

- Expands a 4 zone MAGDUO4 to an 8 zone panel

MAGDUOCC4
MAGDUO4 Zone Conventional Card

- Expands a 4 zone MAGDUO4 to include 4 zones for conventional detectors and call points



MAGDUOSHDR
MAGDUO Head Removal Tool

- Required to remove the chamber from the MAGDUO FlexiPoint detectors, sounders and strobes
- The head removal tool may be attached to an extendable pole