## AlarmSense- 2 Wire

## **RANGE OVERVIEW**

- A powerful C-TEC manufactured, LPCB approved EN54 compliant 2-wire fire alarm panel
- Designed to work with Apollo's AlarmSense range of detectors, call points, sounders and beacons.
- Available with 2, 4 and 8 AlarmSense zone circuits
- Installer-friendly design accommodates easy first fix and straightforward maintenance
- Attractive flush or surface mountable plastic lid and enclosure
- Auxiliary remote, fire, fault and reset outputs
- 'Class change' and alert inputs
- Four conventional sounder circuits (for use with non-AlarmSense sounders)
- Low quiescent current for extended standby times with small batteries
- Intuitive user-friendly interface
- Multiple indicators provide a comprehensive overview of system status
- System expansion connections for up to eight two-wire repeater panels and a range of Relay Output Cards
- Wide range of engineering functions including zone test, coincidence, zone delay and non-latching zones
- Two on-board relays (Fire and Fault)
- Two open-collector outputs (Remote and Reset)



✓ EN54 Third Party Approved

## Please note batteries are not included: All panels require 2 x B/12V/3.2AH/SLA - listed below

Polycarbonate enclosure
RAL7035
380mm (W) x 235mm(H) x 96mm(D) 2, 4 & 8 panels have the same measurements
1.75 Kg (without batteries)

## PANELS

PANELS	
F/CHAS/2	AlarmSense 2-zone fire panel requires 2x B/12V/3.2AH/SLA batteries
F/CHAS/4	AlarmSense 4-zone fire panel requires 2x B/12V/3.2AH/SLA batteries
F/CHAS/8	AlarmSense 8-zone fire panel requires 2x B/12V/3.2AH/SLA batteries
REPEATER PANEL	
F/CHSC/R	AlarmSense 8-zone repeater panel
F/CHSC/RDC	Repeater driver card
S/E20/A	Relay card for use with AlarmSense (fitted in panel)
BATTERIES	
B/12V/3.2AH/SLA	12 Volt 3.2Ah sealed lead acid battery (1 block)
REMOTE INDICATOR	
F/CHRI/AS	AlarmSense remote indicator (Not for use with sounder base units)
CALL POINTS	
F/CHBG/S/AS/2	(55400-894) AlarmSense surface break glass
F/CHBG/AS/COVER	Call Point Cover
S/BG/TESTKEY/AS	Call Point Key
<b>APOLLO DETECTORS &amp; BAS</b>	E
F/BASE/AS	(45681-244) Base for use with AlarmSense dectors
F/CHHF/A/HT/AS	(55000-193) AlarmSense fixed high temperature heat detector Requires Base
SP/CHSM/P/AS	(55000-390) AlarmSense optical detector Requires Base
F/CHHF/AS	(55000-190) AlarmSense 55° rate of rise heat detector Requires Base
APOLLO COMBINATION DE	TECTORS, SOUNDERS & BEACONS
F/CHHF/HT/AS/WB	(55000-197) AlarmSense high temp heat detector and sounder base type CS
F/CHHR/AS/WB	(55000-196) AlarmSense heat detector with sounder base A1R type
F/CHHR/AS/WB/BN	(55000-198) AlarmSense heat detector with sounder base and beacon A1R type
F/CHSM/P/AS/WB	(55000-392) AlarmSense optical detector complete sounder base
F/CHSM/P/AS/WB/BN	(55000-394) AlarmSense optical detector with sounder beacon base
<b>APOLLO SOUNDERS &amp; VISU</b>	AL INDICATORS
F/CHWB/D/AS	(45681-510) AlarmSense base sounder
F/CHWB/D/BN/AS	(45681-509) AlarmSense base mounted electronic sounder/beacon
F/CHWB/BN/RD/AS	(55000-017) AlarmSense open-area red sounder beacon
F/CHWB/RD/AS	(55000-018) AlarmSense open area red sounder
APOLLO OTHER ACCESSOR	ES
F/CHRM/AS	(55000-835) AlarmSense relay module
F/CHWB/AS/CAP/WH	(45681-294) White locking cap for AlarmSense base

