



Keys

- | | |
|---------|---|
| 1. Menu | Selection of operating mode |
| Auto | Mode of running according to the program selected |
| Prog | New for programming mode |
| Prog | To modify an existing program |
| | Checking of the program |
| | Modification of time, date and selection of the winter/summer time change mode. |
| | Holidays |
| 2. +/- | Navigation or setting of values |
| | In auto, mode, selection of overrides, waivers or random operation |
| 3. OK | To validate flashing information on display |
| 4. | To return to the previous step |

You may return into auto mode at any moment using menu.
If no action is taken for 1 min, the switch returns to auto mode.

Major Characteristics

- Product delivered with current time and date set
- Automatic change of winter / summer time
- Programming key
 - For permanent waivers
 - For program copy or save
- Programming for day or group of days
- 56 program steps On, Off
- Impulses (1 sec to 30 min)*
- Permanent overrides On or Off (permanent light on)
- Temporary overrides On or Off (flashing)
- Holiday mode : overrides On or Off between two dates*
- Simulation of presence *
- Display bar graph of daily profile
- Keyboard locking possible
- Programmable with power off
- Back lit display*

* Evolution models E or V only

Connection Diagram

