

Contact Details

Please note that some of the contact details on this PDF document may not be current.

Please use the following details if you need to contact us:

Telephone: 0844 879 3588

Email: customer.services@gdcgroup.co.uk

The customer support section of our website also features a wide range of information which may be of use to you and is available 24 hours a day. It includes:

- Operating and installation instructions
- Easy 'How to use' guides for storage heaters
- Service and repairs
- Where to buy our products
- Literature downloads
- Heating requirement calculator

Visit - www.dimplex.co.uk/support

Quick Start Guide

FX...IPX4 Wall Mounted Fan Heaters

This guide is for quick reference only. Refer to the FX installation and operating instructions for further information


FX20IPX4

On/Off indicator

Indicator will glow red when heating

Pull cord switch

Pull the cord to switch the heater ON and pull the cord again to switch the heater OFF



FX20EIPX4 (runback timer)

On/Off indicator


Indicator will glow red when heating.

Pull cord switch

Pull the cord to switch the heater ON and the heater will run for 15 minutes* and then automatically switch off. To restart the heater for a further 15 minutes pull the cord twice.

To switch the heater off before the timer expires pull the cord once.

*Timer is factory preset at 15 minutes but can be adjusted to run for any time period from 5 – 155mins, please refer to installation and operating instructions for further details



WARNING: A clearance of at least 250mm must be maintained from either side of the heater, 280mm from the top of the heater to the ceiling and must be installed 1800mm from the floor **DO NOT COVER** or obstruct the air inlet or outlet grilles.
PLEASE REFER TO THE OPERATING AND INSTALLATION INSTRUCTIONS FOR FURTHER SAFETY ADVICE.